

























Tablet & Its Pen's Model		Pen's Image	Pen Compatibility
PenPartner (CT)	UP-703E		PenPartner Pen
UD Series	UP-801E		Erasing UltraPen
PL-300 / PL-400	UP-811E		UP-811E UltraPen
Cintiq15X / PL-500	UP-813E		UltraPen 813E
Cintiq18SX	UP-911E-02		Grip Pen
DTU-710	UP-911E-02		Grip Pen
DTU-1931A	UP-817E		Grip Pen, 2 side switch, tail eraser
DTF-720	FP-320		2 side switches, no tail eraser
DTF-510	FP-320E		2 side switches, with tail eraser
DTI-520	IP-100E-01		no side switch, with tail eraser, with pen ID
DTI-520	IP-110-01		2 switches, no tail eraser, with pen ID
Bamboo One Small	FP-500		2 side switch, no tail eraser
PenPartner (FT-0203)	FP-110		1side switch, no tail eraser
BizTablet (CTF-220)	FP-410		2 side switches, no tail eraser
Graphire (ET-0405-R/ ET-0405-U)	EP-100E		Graphire Pen *
Graphire2 (ET-0405A-U/ ET-0507A-U)	EP-120E		Graphire2 Pen *
Graphire3 (CTE-430 / CTE-630)	EP-130E		Graphire3 Pen *
Graphire4 (CTE-440 / CTE-640)	EP-140E		Graphire4 Pen
Banbboo (MTE-450)	EP-150E		2 side switches, with tail eraser
Bamboo Fun (CTE-450 / CTE-650)	EP-155E		Bamboo Fun Pen
Intuos Series (GD)	GP-300E		Intuos1 Pen
Intuos2 Series (XD)	XP-501E		Intuos2 Grip Pen
Intuos3 Series (PTZ) / Cintiq21UX / Cintiq12WX	ZP-501E		Intuos3 Grip Pen
Intuos4 Series (PTK)	KP-501E		Intuos4 Grip Pen

Usually the pens and other accessories are specific to the tablet model they come with. But there are exceptions. For the pens marked with the same color on "Pen Compatibility" column in this web page, they are interchangeable. Pens marked with different colors are not interchangeable.

The pens for Intuos1, Intuos2, Intuos3 and Intuos4 are not interchangeable. Intuos4 supports only Intuos4 input devices such as the Intuos4 Grip Pen, Intuos4 Mouse, etc. Similarly, Intuos4 input devices cannot be used with non-Intuos4 tablets.

Banbboo or Bambooo Fun pen can work on Graphire1,2,3,4 tablet.

The pen for Graphire1, Graphire2, Graphire3 and Graphire4 can be recognized by any of the four types of tablets. That is to say the pens are interchangeable. Mice for Graphire1, Graphire2 are interchangeable. Mice for Graphire3, Graphire4 are interchangeable. Mice for Graphire1, Graphire2 can be recognized by Graphire3 and Graphire4 tablets. But mice for Graphire3, Graphire4 cannot be recognized by Graphire1 or Graphire2 tablets.

There are some differences between similar models sold in Asia Pacific region and other regions (North America, Europe, Japan, China). Only the Asia Pacific models and specifications are shown in this chart.